

INFOCOM

PART NO: G-IMS-TSI

HOW TO APPLY IRON-ONS

1. Pre-heat dry iron to 350° (cotton setting — no steam).
2. Place garment* to be decorated on ironing board (a table with a newspaper on it will also work well).
3. Position IRON-ON with ink side on fabric.
4. PRESS FIRMLY and iron evenly in a slow circular motion for 45-60 seconds. (Be careful to hold IRON-ON in place to avoid smearing.)
5. Allow paper to cool at least 60 seconds.
6. Starting at a corner, peel paper up carefully, checking for adhesion.
7. If design does not transfer completely, repeat steps 4 through 6.
8. If design has transferred, continue to peel paper toward opposite corner.

WASHING INSTRUCTIONS

Wash in warm or cold water (mild detergent is suggested), hang or tumble dry on a low heat setting. Do not iron directly on transfer surface. Do not dry clean.

*For best results, use on 100% cotton and cotton blend fabrics. Not suitable for nylon or man-made fabrics.

Manufactured by **AMERICAN**
Everett, MA 02149 617-389-1400

